

# NOTEBOOK COMPUTER SKIN REFERENCE GUIDE

Thank you for purchasing this MANHATTAN® Notebook Computer Skin. These high-resolution, limited-edition designs are printed on durable polypropylene material that's easily applied — and removed without any remaining residue — to help protect new computers from minor everyday hazards and refresh the look of those with minor scratches and abrasions.

## DESIGNS AVAILABLE:

Racing Car, Model 475686  
Guitar, Model 475679  
Flame, Model 475655


Soccer, Model 475662  
Earth, Model 475693  
Retro, Model 475723  
Cityscape, Model 475716




Shown: Streetscape,  
Model 475709,  
with grid




1. Clean your notebook cover, letting the surface dry before applying the skin.



3. Peel away the back of the skin to expose the adhesive surface.



2. With the grid (back) side of the skin facing up and using the notebook cover dimensions, trim the skin to fit as desired.



4. Carefully position the skin on your notebook cover and press it into place.

**SPECIFICATIONS** • Material: polypropylene • Dimensions: 250 x 375 mm (9.8 x 14.7 in.) • Weight: 62 g (2.2 oz.)

  
**MANHATTAN**™

BRINGING COMPUTERS TO LIFE

MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories.

Ask your local computer dealer for more information or visit us online at

**[www.manhattan-products.com](http://www.manhattan-products.com)**

Copyright © MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.